

QuattroPod Receiver R01 Repair Guide

How to Update QuattroPod Receiver's Firmware

This instruction shows how to manually update firmware of your QuattroPod Receiver R01 through Windows instead of updating it Over-the-Air. **Please be advised that the Windows PC must connect to the internet. Also, we would recommend disabling anti-virus program during the process.**

To update firmware manually, user would need the tools below.

1. QuattroPod Receiver R01
2. SIM card ejector, pencil, paper clip, etc
3. Windows PC
4. USB male to male cable (Type-A)

Step1. Connect your QuattroPod Receiver to power adapter. Please switch off the power of QuattroPod by pressing the "POWER" button.




Step2. Keep pressing the "RESET" button with pen, paper clip, SIM ejector, etc. Then press "POWER" button to activate QuattroPod Receiver.




Step3. Connect your QuattroPod Receiver to Windows PC via USB male to male cable




Step4. Extract "QuattroPod Receiver Repair Tool". Then click "EZCastUpdate.exe".




Step5. If device successfully connected with your PC, the EZCastUpdate application would show "Device connected" as the picture below. Click "Download" button, the system would start downloading firmware.




Step6. Now the system is downloading firmware. **Please be advised that DO NOT turn off the power of QuattroPod Receiver during the process.**



Step7. Once download process is done, please click "Upgrade" button.



Step8. Now the system is installing the latest firmware. **Please be advised that DO NOT turn off the power of QuattroPod Receiver during the process.**



Step9. Congratulation! The QuattroPod Receiver has been updated to the latest firmware.

